


Index
Side Loader Twin Spare Parts

Page 1. Index
Page 2-7. Behållare - Body
Page 8-11. Baklucka bred - Tailgate wide
Page 12-15. Baklucka smal - Tailgate narrow
Page 16-23. Komprimatorhus - Compress module
Page 24-25. Kärldångare STD - Bin catcher STD
Page 26-31. Sidlastararm - Loading arm
Page 32-37. Teleskopisk lastarm - Telescopic loading arm
Page 38-42. Vagga SL - Cradle SL
Page 43-47. Vagga SL högt läge - Cradle SL high point
Page 48-49. Hydraultank - Hydraulic tank
Page 50-51. Skyddsstötta SL - Support leg SL

Note! The images are for reference only.
Components marked with * contact
spare part branch.


SL Twin toppsammanställning-SL Twin top assembly




1. Behållare-Body
2. Komprimator-Compress module
3. Baklucka bred-Tailgate wide
4. Baklucka smal-Tailgate narrow
5. Lastarm-Loading arm
6. Vagga-Cradle
7. Hydraultank-Hydraulic tank

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Sidlastarbehållare Twin-Body Side Loader Twin



Note! The images are for reference only.
Components marked with * contact
spare part branch.



20	Adapter	Adapter	1505758	
19	Adapter	Adapter	1505850	
18	Adapter	Adapter	1505849	
17	Bricka	Washer	1516195	
16	Bult	Bolt	1516194	
15	Bult	Bolt	1506882	3
14	Låsplatta	Lock plate	504337	2
13	Bult	Bolt	504345	3
12	Bussning	Bushing	1505505	
11	Bussning	Bushing	1512299	
10	Bult	Bolt	1516173	
9	Skruv	Screw	1516174	
8	Saxpinne	Cotter pin	1516196	
7	Skruv	Screw	1505263	
6	Bricka	Washer	1504899	
5	Bricka	Washer	1506926	
4	Låsplatta	Lock plate	1506881	
3	Bult	Bolt	1516156	
2	Hydraulcylinder	Hydraulic cylinder	1523878	2
1	Arm SL	Arm SL	1516155	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Hydraulcylindrar med länkar-Hydraulic cylinders with links


1525308
2013-12-03

Sidlastarbehållare Twin-Body Side
Loader Twin

Rev. 1


Date: 2014-03-28

Page
2 / 5




11	Skyddsplåt	Cover	1525875	1
10	Skruv	Screw	1506538	
9	Adapter	Adapter	1510165	
8	Adapter	Adapter	1506692	
7	Adapter	Adapter	1506236	
6	Adapter	Adapter	1506074	
5	Ventil	Valve	1506547	
4	Adapter	Adapter	1519191	
3	Skruv	Screw	1505263	
2	Bricka	Washer	1504899	
1	Blindnitmutter	Rivet nut	1504886	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



5	Slangskydd höger	Hose cover right	1523930	2
4	Slangskydd vänster	Hose cover left	1516227	3
3	Skruv	Screw	1504922	
2	Bricka	Washer	1504899	
1	Blindnitmutter	Rivet nut	1504886	
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.





5	Adapter	Adapter	1516429	
4	Adapter	Adapter	1505758	
3	Radialtätning	Radial seal	1515638	
2	Bussning	Bushing	1505530	
1	Expanderbult	Expansion bolt	1515428	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only. Components marked with * contact spare part branch.

Bred baklucka SL Twin- Wide Tailgate Side Loader Twin



Note! The images are for reference only.
Components marked with * contact
spare part branch.




Note! The images are for reference only.
Components marked with * contact
spare part branch.

15	Skruv	Screw	1505265	
14	Skruv	Screw	1505263	
13	Låsmutter	Locking nut	1505255	
12	Bricka	Washer	1504903	
11	Bricka	Washer	1504899	
10	Skruv	Screw	1505264	
9	Mutter	Nut	1504839	
8	Låshake	Lock latch	1509435	7
7	Stöthållare	Support leg holder	1516597	2
6	Låssprint	Locking pin	1507262	
5	Låsmutter	Locking nut	1505258	
4	Bricka	Washer	1504901	
3	Skruv	Screw	1508833	
2	Skyddsstötta	Support leg	1505804	4
1				
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Låsning och stödben-Lock hooks and support leg

1516576 Bred baklucka SL Twin-WideTailgate
2013-12-03 Side Loader Twin

Rev. 1 Date: 2014-03-27





14	Skruv	Screw	1504922	
13	Skruv	Screw	1505262	
12	Bricka	Washer	1504899	
11	Blindnitmutter	Rivet nut	1504886	
10	Kantskyddslist	Edge trim	1506828-7	
9	Gummilishållare	Rubber seal holder	1516612	
8	Gummilishållare rak	Rubber seal holder	1516611	
7	Gummilishållare 90°	Rubber seal holder	1516610	
6	Gummilishållare rak	Rubber seal holder	1516609	
5	Gummilishållare 90°	Rubber seal holder	1516608	
4	Täckplåt vänster SL	Cover plate	1516650	
3	Tätningsslist	Rubber seal	1505165-7	
2	Induktiv givare	Inductive sensor	1511077	
1				
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Gummitätning, kabelskydd-Rubber gasket, Wire cover

1516576 Bred baklucka SL Twin-WideTailgate
2013-12-03 Side Loader Twin
Rev. 1 Date: 2014-03-27




Note! The images are for reference only.
Components marked with * contact
spare part branch.

6	Skruv	Screw	1504922	
5	Bricka	Washer	1504899	
4	Blindnitmutter M8	Rivet nut	1504886	
3	Gummilist 0540	Edge trim	1504928-11	
2	Täcklock	Cover plate	1516591	
1				
ITEM NO.	Benämning	Title	Part no	YAP.Rev



Täcklock-Cover plate

1516576	Bred baklucka SL Twin-WideTailgate
2013-12-03	Side Loader Twin
Rev. 1	Date: 2014-03-27

Smal baklucka SL Twin- Narrow Tailgate Side Loader Twin



Note! The images are for reference only.
Components marked with * contact
spare part branch.




Note! The images are for reference only.
Components marked with * contact
spare part branch.

14	Skruv	Screw	1505265	
13	Bricka	Washer	1504903	
12	Låsmutter	Locking nut	1505255	
11	Skruv	Screw	1505263	
10	Bricka	Washer	1504899	
9	Skruv	Screw	1505264	
8	Mutter	Nut	1504839	
7	Låshake	Lock latch	1509435	7
6	Stöthållare	Support leg holder	1516597	2
5	Låssprint	Locking pin	1507262	
4	Låsmutter	Locking nut	1505258	
3	Bricka	Washer	1504901	
2	Skruv	Screw	1508833	
1	Skyddsstötta	Support leg	1505804	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Låsning och stödben-Lock hooks and support leg

1516692 Smal baklucka SL Twin-Narrow
2013-12-03 Tailgate Side Loader Twin

Rev. 1 Date: 2014-03-27





13	Skruv	Screw	1504922	
12	Bricka	Washer	1504899	
11	Skruv	Screw	1505267	
10	Blindnitmutter	Rivet nut	1504886	
9	Kantskyddslist	Edge trim	1506828-7	
8	Induktiv givare	Inductive sensor	1511077	
7	Gummilishållare rak smal	Rubber seal holder	1516649	
6	Gummilishållare rak	Rubber seal holder	1516611	
5	Gummilishållare 90°	Rubber seal holder	1516608	
4	Gummilishållare	Rubber seal holder	1516612	
3	Gummilishållare 90°	Rubber seal holder	1516610	
2	Tätninglist	Rubber seal	1505165-8	
1	Täckplåt SL höger	Cover plate	1516652	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Gummitätning, kabelskydd-Rubber gasket, Wire cover

1516692 Smal baklucka SL Twin-Narrow
2013-12-03 Tailgate Side Loader Twin

Rev. 1 Date: 2014-03-27




Note! The images are for reference only.
Components marked with * contact
spare part branch.

5	Skruv	Screw	1504922	
4	Bricka	Washer	1504899	
3	Blindnitmutter	Rivet nut	1504886	
2	Täcklock	Cover plate	1516591	
1	Gummilist	Edge trim	1504928-11	
ITEM NO.	Benämning	Title	Part no	YAP.Rev



Täcklock-Cover plate

1516692 Smal baklucka SL Twin-Narrow
2013-12-03 Tailgate Side Loader Twin
Rev. 1 Date: 2014-03-27

Sidlastare Twin Komprimatorhus Side Loader Twin Compress module




Note! The images are for reference only.
Components marked with * contact
spare part branch.




12	Takplåt	Roof plate	1524893	1
11	Täcklock	Cover plate	1525868	1
10	Slangfäste	Hose bracket	1506029	
9	Slangfäste	Hose bracket	1509709	
8	Hydraulcylinder	Hydraulic cylinder	1518817	2
7	Hydraulcylinder	Hydraulic cylinder	1516219	
6	Vikvägg	Folding wall	1525864	4
5	Skruv	Screw	1506640	
4	Bricka	Washer	1504899	
3	Pendel smal	Pendulum narrow	1525839	2
2	Pendel bred	Pendulum wide	1525838	2
1	Hydraulcylinder	Hydraulic cylinder	1525056	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



14	Skruv	Screw	1506680	
13	Nordlock 10	Nordlock 10	1523078	1
12	Givarfäste pendel	Sensor bracket	1525867	1
11	Givarfjäder (smal pendel)	Sensor flag	1525870	1
10	Givarfjäder (bred pendel)	Sensor flag	1525869	1
9	Induktiv givare	Inductive sensor	504768	
8	Givarfäste	Sensor bracket	1525866	1
7	Bussning	Bushing	1516539	
6	Bussning	Bushing	1514831	
5	Skruv	Screw	1506640	
4	Skruv	Screw	1506640	
3	Bricka	Washer	1504899	
2	Axel Pendelcylinder	Axle Cylinder	1525859	2
1	Hydraulcylinder	Hydraulic cylinder	1525056	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.



4	Adapter	Adapter	1506192	
3	Radialtätning	Radial seal	1515638	
2	Bussning	Bushing	1519571	
1	Hydraulcylinder	Hydraulic cylinder	1525031	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev



Note! The images are for reference only.

Hydraulcylinder-Hydraulic cylinder




15	Givarfjäder (smal pendel)	Sensor flag	1525870	1
14	Givarfjäder (bred pendel)	Sensor flag	1525869	1
13	Radialtätning	Radial seal	1516530	
12	Bussning	Bushing	1515357	
11	Bussning	Bushing	1518404	
10	Skruv	Screw	1506640	
9	Bricka	Washer	1504899	
8	Distansring	Spacer	1516519	
7	Distansring	Spacer	1516522	
6	Distansring	Spacer	1523140	1
5	Distansring	Spacer	1516523	
4	Svetsning pendel SL smal (2013)	Pendulum narrow	1525839	2
3	Expanderbult	Expansion bolt	1516512	
2	Expanderbult	Expansion bolt	1516510	
1	Pendel bred	Pendulum wide	1525838	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.



23	Låsmutter	Locking nut	1505256	
22	Bricka	Washer	1504898	
21	Gummidämpare	Bumper	1525264	1
20	Skruv	Screw	1505262	
19	Blindnitmutter	Rivet nut	1504886	
18	Adapter	Adapter	1505700	
17	Radialtätning	Radial seal	1515635	
16	Bussning	Bushing	1518675	
15	Givarfäste	Sensor bracket	1522435	1
14	Hydraulcylinder	Hydraulic cylinder	1518817	2
13	Bult	Bolt	1525422	1
12	Bult	Bolt	1518676	3
11	Arm	Arm	1525905	1
10	Vikvägg	Folding wall	1525864	4
9	Induktiv givare	Inductive sensor	504768	
8	Skruv	Screw	1508794	
7	Skruv	Screw	1505613	
6	Bricka	Washer	1504901	
5	Skruv	Screw	1512953	
4	Radialtätning	Radial seal	1515636	
3	Bussning	Bushing	1518826	
2	Centrum	Center	1516491	
1	Låsplatta	Locking plate	504335	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.




8	Slangbrottsventil	Hose break valve	1519791	
7	Adapter	Adapter	504730	
6	Låsplatta	Locking plate	504332	2
5	Saxpinne	Cotter pin	1519179	
4	Bult	Bolt	504781	
3	Bult	Bolt	1516542	
2	Hydraulcylinder	Hydraulic cylinder	1516219	
1	Skruv	Screw	1512953	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.

Tippcylinder-Tilt cylinder


1525871	Reservdelar Komprimator SL Twin -	Page 7 / 8
2013-11-28	Spare parts Compress module SL Twin	
Rev. 1	Date: 2014-03-28	




7	Skruv	Screw	1505263	
6	Låsmutter	Locking nut	1505255	
5	Bricka	Washer	1504899	
4	Blindnitmutter	Rivet nut	1504886	
3	Sl takplåt mitten	Roof plate	1524893	1
2	Sl takplåt mitten	Roof plate	1524892	1
1	Takplåt sidlastare twin	Roof plate	1525024	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.

Kärlfångare Sidlastare STD Bin catcher Side loader STD




Note! The images are for reference only.
Components marked with * contact
spare part branch.




19	Skruv	Screw	1505263	
18	Bricka	Washer	1504899	
17	Adapter	Adapter	1505700	
16	Hydraulcylinder	Hydraulic cylinder	1521146	
15	Adapter	Adapter	1505025	
14	Induktiv givare	Sensor	1511077	
13	Givarfäste	Sensor bracket	1521725	1
12	Skruv	Screw	1512953	
11	Radialtätning	Seal	1515635	
10	Bussning	Bushing	1518675	
9	Bussning	Bushing	1508308	
8	Låsplatta	Locking plate	504335	2
7	Bult	Bolt	1519356	
6	Kärlfångarfäste SL	Bin cather bracket	1521833	2
5	Kärlfångarfäste SL	Bin cather bracket	1521860	2
4	Kärlfångararm SL	Bin cather arm	1516709	3
3	Fjäder	Spring	1509289	
2	Gaffellänk	End fitting	1507830	3
1	Kärlfångare SL	Bin catcher SL	1521832	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Sidlastararm - Loading arm Side Loader



Note! The images are for reference only.
Components marked with * contact
spare part branch.




Note! The images are for reference only.
Components marked with * contact
spare part branch.

3	Mellanarm SL enkel	Middle arm SL	1523924	1
2	Inre Arm SL	Inner arm SL	1523923	2
1	Hydraulcylinder	Hydraulic cylinder	1515134	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Sidlastare arm-Loading Arm Side Loader

1523914	Sidlastare Arm-Loading Arm Side Loader
2013-11-29	
Rev. 1	Date: 2014-03-28




14	Hydraulcylinder	Hydraulic cylinder	1523129	2
13	Slangbrottsventil	Hose break valve	1514541	2
12	Bussning	Bushing	1518675	
11	Bussning	Bushing	1519572	
10	Radialtätning	Radial seal	1515635	
9	Radialtätning	Radial seal	1515638	
8	Bussning	Bushing	1519571	
7	Adapter	Adapter	1506192	
6	Adapter	Adapter	1506236	
5	Länk	Link	1515585	
4	Länk	Link	1518333	
3	Expanderbult 30x186	Expansion bolt	1515452	1
2	Expanderbult 50x122	Expansion bolt	1515428	1
1	Expanderbult 50x446	Expansion bolt	1515447	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




20	Distans	Spacer	1525265	1
19	Slangfäste	Hose bracket	1506029	
18	Skruv	Screw	1518847	2
17	Givarfästeplåt	Sensor plate	1525200	1
16	Vinkelgivare	Angle sensor	1522902	2
15	Skruv	Screw	1505263	
14	Bricka	Washer	1504899	
13	Skruv	Screw	1512861	
12	Låsmutter	Locking nut	1505256	
11	Bricka	Washer	1504898	
10	Arm 2 till vinkelgivare	Arm 2 angle sensor	1525197	1
9	Vibrationsdämpare	Bumper	1525194	1
8	Arm vinkelgivare	Arm angle sensor	1525199	1
7	Anslagsdämpare	Bumper	1517349	
6	Bricka	Washer	1504900	
5	Låsmutter	Locking nut	1505257	
4	Bussning	Bushing	1523903	1
3	Radialtätning	Radial seal	1515638	
2	Mellanarm SL enkel	Middle arm SL	1523924	1
1	Expanderbult	Expansion bolt	1523902	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



17	Blixtljus	Flashlight	1525416	2
16	Slangfäste	Hose bracket	1506029	
15	Slangfäste	Hose bracket	1509709	
14	Mutter	Nut	1504834	
13	Gummidämpare	Bumper	1525264	1
12	Bricka	Washer	1504898	
11	Plastskydd	Plastic cover	1525257	1
10	Skruv	Screw	1508603	
9	Plåt	Plate	1523942	1
8	Slangfäste	Hose bracket	1513267	
7	Adapter	Adapter	1505760	
6	Adapter	Adapter	1516429	
5	Hydraulslang	Hose	1518511	1
4	Skruv	Screw	1509326	
3	Adapter	Adapter	1517209	
2	Bult	Bolt	1516048	
1	Inre Arm SL	Inner arm SL	1523923	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




16	Skruv	Screw	1512953	
15	Låsplatta	Locking plate	504334	2
14	Skruv	Screw	1507496	
13	Bricka	Washer	1504900	
12	Låsmutter	Locking nut	1505257	
11	Bricka	Washer	1504901	
10	Skruv	Screw	1505315	2
9	Glidklots	Sliding block	1519611	
8	Bult	Bolt	504339	
7	Lock	Cover	1515155	
6	Glidklots	Sliding block	1515156	
5	Stopp	End plate	1515153	
4	Stopp	End plate	1515152	
3	Glidklots	Sliding block	1515149	
2	Hydraulcylinder 50x25-1600 SL	Hydraulic cylinder	1515134	2
1	Utskjut SLarm	Extension arm	1519562	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Sidlastare teleskopisk arm
Telescopic arm Side loader




Note! The images are for reference only.
Components marked with * contact
spare part branch.




3	Hydraulcylinder	Hydraulic cylinder	1519550	
2	Mellanarm SL enkel	Midlle arm SL	1523924	1
1	Inre Arm SL	Inner arm SL	1523923	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




14	Adapter	Adapter	1506192	
13	Slangbrottsventil	Hose break valve	1514541	2
12	Bussning	Bushing	1518675	
11	Bussning	Bushing	1519572	
10	Radialtätning	Radial seal	1515635	
9	Radialtätning	Radial seal	1515638	
8	Bussning	Bushing	1519571	
7	Adapter	Adapter	1506236	
6	Hydraulcylinder	Hydraulic cylinder	1523129	2
5	Länk	Link	1515585	
4	Länk	Link	1518333	
3	Expanderbult	Expansion bolt	1515452	1
2	Expanderbult	Expansion bolt	1515449	1
1	Expanderbult	Expansion bolt	1515447	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




20	Distans	Spacer	1525265	1
19	Slangfäste	Hose bracket	1506029	
18	Skruv	Screw	1518847	2
17	Givarfäste	Sensor bracket	1525202	1
16	Vinkelgivare	Angle sensor	1522902	2
15	Skruv	Screw	1505263	
14	Bricka	Washer	1504899	
13	Skruv	Screw	1512861	
12	Låsmutter	Locking nut	1505256	
11	Bricka	Washer	1504898	
10	Arm 2 till vinkelgivare	Arm 2 angle sensor	1525197	1
9	Vibrationsdämpare	Bumper	1525194	1
8	Arm 1 till vinkelgivare	Arm 1 angle sensor	1525196	1
7	Anslagsdämpare	Bumper	1517349	
6	Låsmutter	Locking nut	1505257	
5	Bricka	Washer	1504900	
4	Bussning	Bushing	1523903	1
3	Radialtätning	Radial seal	1515638	
2	Mellanarm SL enkel	Midel arm SL	1523924	1
1	Expanderbult	Expansion bolt	1523902	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



16	Blixtljus	Flashlight	1525416	2
15	Slangfäste	Hose bracket	1506029	
14	Slangfäste	Hose bracket	1509709	
13	Mutter	Nut	1504834	
12	Gummidämpare	Bumper	1525264	1
11	Bricka	Washer	1504898	
10	Plastskydd	Plastic cover	1525257	1
9	Skruv	Screw	1508603	
8	Bricka	Washer	1504898	
7	Plåt	Plate	1523942	1
6	Hydraulslang	Hose	1518511	3
5	Adapter	Adapter	1504975	
4	Adapter	Adapter	1505760	
3	Skruv	Screw	1509326	
2	Bult	Bolt	1516048	
1	Inre Arm SL	Arm inner SL	1523923	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




Note! The images are for reference only.
Components marked with * contact
spare part branch.

17	Fästplåt för IFM modul, SL	Mounting plate IFM module	1526206	1
16	Skruv	Screw	1519630	
15	Skruv	Screw	1512953	
14	Fäste	Bracket	1519725	
13	Kabelränna	E-chain cover	1519718	
12	Kabelkedjefäste	E-chain bracket	1523632	2
11	E-kedja	E-chain	1519692	
10	Låsplatta	Locking plate	504334	2
9	Stopp-plåt	End plate	1519583	
8	Glidklots	Sliding block	1519628	
7	Hydraulcylinder	Hydraulic cylinder	1519550	
6	Utskjut inre SL teleskop	Telscopic arm inner SL	1519597	
5	Glidklots	Sliding block	1519611	
4	Bult	Bolt	504339	
3	Stopp-plåt	End plate	1519629	
2	Glidklots	Sliding block	1515149	
1	Utskjut SL teleskoparm	Telescopic arm SL	1519595	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Vagga STD sidlastare - Cradle STD Side Loader



Note! The images are for reference only.
Components marked with * contact
spare part branch.




5	Radialtätning	Radial Seal	1515638	
4	Johnson Bussning	Johnson Bushing	1519572	
3	Radialtätning	Radial Seal	1515636	
2	Johnson Bussning	Johnson Bushing	1518826	
1	Expanderbult	Expansion bolt	1515435	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.


Övre bussningar och bult-Upper bushings and bolt

1523883 Vagga SL STD-Cradle SL STD
2013-11-29
Rev. 1 Date: 2014-03-28




12	Nordlock 16	Nordlock 16	1506742	
11	Skruv	Screw	1506711	
10	KM mutter	KM Nut	504576	
9	Skruv	Screw	1506711	
8	Nordlock 16	Nordlock 16	1506742	
7	Axel	Axle	1515580	2
6	Axeltapp	Shaft	1515627	
5	Skruv	Screw	1507457	
4	Lagerhus	Bearing Housing	1518303	
3	Tätning	Seal	1513822	
2	Lock	Cover	1515626	
1	Koniskt Rullager	Bearing	1515695	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



19	Adapter	Adapter	1505760	
18	Kamfäste SL höger	Comb bracket right	1525602	1
17	Kamfäste SL vänster	Comb bracket left	1525605	1
16	Hydraulcylinder	Hydraulic cylinder	1524788	1
15	Skruv	Screw	1525599	1
14	Bricka	Washer	1504900	
13	Segersäkring	Ring, snap	1506684	
12	Skruv	Screw	1504922	
11	Bricka	Washer	1504899	
10	Skruv	Screw	1508794	
9	Nordlock 12	Nordlock 12	1510522	
8	Bricka	Washer	1504901	
7	Låsmutter	Locknut	1505258	
6	Adapter	Adapter	1506074	
5	Plåt	Block	1517076	
4	Bussning	Bushing	1515720	
3	Bult	Bolt	1505773	
2	Kärllåsklaff	Bin lock Flap	1515648	2
1	Ram T-vagga SL	Frame T-Cradle SL	1518981	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




4	Bricka	Washer	1504899	
3	Gummihållare	Rubber fender holder	1512986	
2	Gummifender	Rubber fender	1512985	
1	Skruv	Screw	1505262	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Vagga SL högt läge-Cradle SL high point



Note! The images are for reference only.
Components marked with * contact
spare part branch.




5	Bussning	Bushing	1519572	
4	Radialtätning	Radial seal	1515638	
3	Expanderbult	Expansion bolt	1515435	1
2	Radialtätning	Radial seal	1515636	
1	Bussning	Bushing	1518826	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.


Övre bussningar och bult-Upper bushings and bolt

1523922	Vagga SL högt läge-Cradle SL high point	Page 2 / 5
2014-01-30		
Rev. 1	Date: 2014-03-28	




12	Nordlock 16	Nordlock 16	1506742	
11	Skruv	Screw	1506711	
10	KM mutter	KM nut	504576	
9	Skruv	Screw	1506711	
8	Nordlock 16	Nordlock 16	1506742	
7	Axel	Axle	1515580	2
6	Axeltapp	Shaft	1515627	
5	Skruv	Screw	1507457	
4	Lagerhus	Bearing housing	1518303	
3	Tätning	Seal	1513822	
2	Lock	Cover	1515626	
1	Koniskt Rullager	Bearing	1515695	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



19	Adapter	Adapter	1505760	
18	Kamfäste SL höger	Comb bracket right	1525602	1
17	Kamfäste SL vänster	Comb bracket left	1525605	1
16	Hydraulcylinder	Hydraulic cylinder	1524788	1
15	Skruv	Screw	1525599	1
14	Bricka	Washer	1504900	
13	Segersäkring	Ring, snap	1506684	
12	Skruv	Screw	1504922	
11	Bricka BRB 8,4	Washer	1504899	
10	Skruv	Screw	1508794	
9	Nordlock 12	Nordlock 12	1510522	
8	Bricka	Washer	1504901	
7	Låsmutter	Locking nut	1505258	
6	Adapter	Adapter	1506074	
5	Plåt	Block	1517076	
4	Bussning	Båshing	1515720	
3	Bult	Bolt	1505773	
2	Kärllåsklaff	Bin lock Flap	1515648	2
1	Ram T-vagga SL	Frame T-Cradle SL	1518981	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




7	Skruv	Screw	1505686	
6	Låsmutter	Locking nut	1505255	
5	Skruv	Screw	1504922	
4	Gummidämpare	Rubber damper	1507924	
3	Bricka	Washer	1504899	
2	Gummihållare	Rubber fender holder	1512986	
1	Gummifender	Rubber fender	1512985	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Hydraultank och filter SL, SL Twin Hydraulic tank and filter SL, SL Twin




Note! The images are for reference only.
Components marked with * contact
spare part branch.




24	Filterinsats returfilter	Filter element	1519435	
23	Luftfilter	Air filter	1525403	2
22	Skruv	Screw	1506628	
21	Bricka	Washer	1504900	
20	Adapter	Adapter	1516695	
19	Adapter	Adapter	1513228	
18	Returfilter	Filter, return	1516693	
17	Skruv	Screw	1506640	
16	Bricka	Washer	1504899	
15	Packning	Gasket	1525690	2
14	Andningslock	Breather	1525689	1
13	Skruv	Screw	1515377	
12	Tredobricka	Tredo washer	1515376	
11	Adapter	Adapter	1505758	
10	Adapter	Adapter	1507478	
9	Tanknivådekal MD	Decal oil level	1506956	
8	Mätrör oljenivå	Oil level tube	1522825	1
7	Vinkel mätrör	Elbow	1505799	
6	Adapter	Adapter	1505769	
5	Kulventil	Valve	1505816	
4	Slangnippel	Hose nipple	1507103	
3	Kulventil	Valve	1505815	
2	Tryckgivare	Pressure sensor	1517308	
1	Hydruaultank sidlastare	Hydraulic tank side loader	1516578	5
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Skyddsstötta SL-Support leg SL



Note! The images are for reference only.
Components marked with * contact
spare part branch.



9	Skruv	Screw	1505263	
8	Låsmutter	Locking nut	1505255	
7	Bricka	Washer	1504899	
6	Låssprint	Locking pin	1507262	
5	Skruv	Screw	1516803	
4	Låsmutter	Locking nut	1508499	
3	Bricka	Washer	1508498	
2	Vibrationsdämpare	Bumper	1507924	
1	Skyddsstötta	Support leg	1516795	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.