


Index Twin Spare Parts


Page 1.	Index
Page 2-7.	Behållare - Body
Page 8-12.	Baklucka bred - Tailgate wide
Page 13-16.	Press & transportplatta bred - Press & Transport plate wide
Page 17-21.	Baklucka smal - Tailgate narrow
Page 22-25.	Press & transportplatta smal - Press & Transport plate narrow
Page 26-33.	Kärlyft bred - Bin lift wide
Page 34-40.	Kärlyft smal - Bin lift narrow
Page 41-43.	Kärllåsning bred - Bin lock wide
Page 44-46.	Kärllåsning smal - Bin lock narrow
Page 47-48.	Kärlfångare bred - Bin catcher wide
Page 49-50.	Kärlfångare smal - Bin catcher narrow
Page 51-52.	Hydraultank - Hydraulic tank
Page 53-54.	Inspektionslucka - Inspection cover

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Twinbehållare toppsammanställning Twin Body Top assembly




Note! The images are for reference only.
Components marked with * contact
spare part branch.




17	Fästplatta	Plate	504655	
16	Rör	Pipe	1507366	
15	Skruv	Screw	1506711	
14	Skruv	Screw	1507496	
13	Bricka	Washer	1504903	
12	Bricka	Washer	1504900	
11	Mutter	Nut	1504836	
10	Skruv	Screw	1505538	
9	Låsmutter	Locking nut	1505255	
8	Bricka	Washer	1504899	
7	Skruv	Screw	1505263	
6	Sido glidkloss	Flank Slide block	504758	
5	Gummi	Rubber	504756	
4	Låsplatta	Locking plate	504663	
3	Undre glidkloss	Lower Slide block	504659	
2	Övre glidkloss	Upper Slide block	504650	
1	Urlastningsplatta Twin bred	Unloading plate Twin wide	1509476	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



17	Rör	Pipe	1507366	
16	Skruv	Screw	1506711	
15	Skruv	Screw	1507496	
14	Bricka	Washer	1504900	
13	Bricka	Washer	1504903	
12	Mutter	Nut	1504836	
11	Skruv	Screw	1505538	
10	Låsmutter	Locking nut	1505255	
9	Bricka	Washer	1504899	
8	Skruv	Screw	1505263	
7	Sido glidkloss	Flank Slide block	504758	
6	Gummi	Rubber	504756	
5	Låsplatta	Locking plate	504663	
4	Undre glidkloss	Lower Slide block	504659	
3	Fästplatta	Plate	504655	
2	Övre glidkloss	Upper Slide block	504650	
1	Urlastningsplatta Twin smal	Unloading plate Twin narrow	1509535	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



8	Bricka BRB 13	Washer	1504901	
7	Skruv M6S M12x20 fzb	Screw	1507497	
6	Nedre högra låsplåt	Lower right locking plate	504686	
5	Nedre vänstra låsplåt	Lower left locking plate	504687	
4	Låsplåt	Locking plate	503327	
3	Låsplåt	Locking plate	503326	
2	Bult	Bolt	504781	
1	Urlastningscylinder	Unloading cylinder	-	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Behållarspecifika cylindernummer
Bodyspecific cylinder part numbers

L=3300 - 1507594
L=3350 - 1507594
L=3500 - 1511904
L=3600 - 1508194
L=3700 - 1515521
L=3800 - 1505207
L=3900 - 1508278
L=4000 - 504693
L=4100 - 1509061
L=4200 - 1500302
L=4300 - 1522058
L=4600 - 1507000
L=4700 - 1507558
L=4800 - 1505518
L=4900 - 1514072
L=5000 - 1505994
L=5100 - 1517557
L=5200 - 1505523
L=5300 - 1510146
L=5400 - 1515223
L=5500 - 1511408
L=5600 - 1506927
L=5800, 50 mm flyttad vägg - 50 mm moved inner wall 1517775/1511408
L=5900 - 1513500
L=5900, 50 mm flyttad vägg - 50 mm moved inner wall 1513500/1506927
L=6000 - 1515971
L=6200 - 1516291
L=6200, 50 mm flyttad vägg - 50 mm moved inner wall 1516291/1513500

Note! The images are for reference only.
Components marked with * contact
spare part branch.


1510787

2014-03-10

Rev. 1

Twinbehållare toppsammanställning-
Twin Body Top assembly


Date: 2014-03-27




22	Slitplast givare	Hard plastic, sensor	1521340	
21	Induktiv givare	Inductive sensor	1511077	
20	Givarfäste	Sensor bracket	1509906	2
19	Plåt givare (höger)	Sensor flag (right)	1525156	2
18	Plåt givare (vänster)	Sensor flag (left)	1525157	1
17	Rundbricka	Washer	1506617	
16	Hydraulcylinder	Hydraulic cylinder	1523878	2
15	Bult	Bolt	1506869	
14	Skruv	Screw	1505263	
13	Bricka	Washer	1504899	
12	Låsplatta	Locking plate	1506881	
11	Bult	Bolt	1506882	3
10	Rundbricka	Washer	1506926	
9	Bussning	Bushing	1512299	
8	Bussning	Bushing	1505505	
7	Länkstång	Link rod	1509095	
6	Länkhuvud	Link head	1505581	
5	Mutter	Nut	1505583	
4	Låsplatta	Locking plate	504337	2
3	Bult	Bolt	1509345	
2	Bult	Bolt	504345	3
1	Arm	Arm	1509094	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Twin baklucka bred-Twin Tailgate wide



Note! The images are for reference only.
Components marked with * contact
spare part branch.




5	Låsplatta	Locking plate	504332	2
4	Bult	Bolt	1521140	
3	Press & transportplatta Twin bred	Press & Transport plate Twin wide	1520364	8
2	Bricka	Washer	1504899	
1	Skruv	Screw	1505263	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.


Press & transportplatta Twin bred-Press & Transport
plate Twin wide

1526349	Twin baklucka bred-Twin Tailgate wide
2014-03-12	
Rev. 1	Date: 2014-03-28




18	Gummilsthållare övre	Rubber seal holder	1525049	1
17	Täcklock	Cover plate	1523829	1
16	Täckplåt höger	Cover right	1526417	1
15	Skyddsstötta	Support leg	1505284	
14	Låshake	Lock latch	1509435	7
13	Täckplåt vänster	Cover left	1509388	3
12	Skruv	Screw	1505264	
11	Bricka	Washer	1504899	
10	Skruv	Screw	1505263	
9	Skruv	Screw	1505265	
8	Mutter	Nut	1504839	
7	Bricka	Washer	1504903	
6	Skruv	Screw	1507699	
5	Gummilsthållare	Rubber seal holder	1514505	
4	Gummilsthållare sida	Rubber seal holder	1525050	2
3	Gummilsthållare 90°	Rubber seal holder	1525034	1
2	Rak gummilsthållare	Rubber seal holder	1509130	
1	Tätninglist Twin bred	Rubber seal	1521644	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



3	Induktiv givare	Inductive sensor	1511077	
2	Slitplast givare	Hard plastic, sensor	1521340	
1	Induktiv givare	Inductive sensor	504768	
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




11	Låsmutter	Locking nut	1505255	
10	Bricka	Washer	1504899	
9	Skruv	Screw	1505267	
8	Gångjärn	Hinge	504609	
7	Skyddsstötta	Safety support	504618	
6	Takplåt bred Twin	Roof plate Twin wide	1509928	
5	Vinkel	Angle bracket	1509923	
4	Skruv	Screw	1505263	
3	Bricka	Washer	1504899	
2	Låsmutter	Locking nut	1505255	
1	Skyddsplåt Twin bred	Cover	1509922	6
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Press & transportplatta Twin Press & Transport plate Twin




Note! The images are for reference only.
Components marked with * contact
spare part branch.




15	Skruv	Screw	1505614	
14	Låsmutter	Locking nut	1505255	
13	Skruv	Screw	1504922	
12	Fjäderplåt	Sensor plate	1521344	
11	Fjäderfäste	Bracket	1522249	3
10	Bricka	Washer	1504899	
9	Skruv	Screw	1510249	2
8	Skruv	Screw	1522843	1
7	Låskil Glidklots	Locking wedge	1523101	1
6	Glidbussning	Bushing	1514702	
5	Skruv	Screw	1505315	2
4	Bricka BRB 13	Washer	1504901	
3	Plåt	Plate	1508925	
2	Glidbelägg	Sliding skid	1508960	
1	Glidkloss	Sliding block	1508926	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



24	Distans	Spacer	1523073	1
23	Skruv	Screw	1508815	
22	Nordlock 12	Nordlock 12	1510522	
21	Medbringare	Fork	1522899	1
20	Vinkelgivare	Angle sensor	1522902	2
19	Givarfäste	Sensor bracket	1522821	3
18	Skruv	Screw	1506680	
17	Bricka	Washer	1504900	
16	Skruv	Screw	1522842	1
15	Nordlock M20	Nordlock M20	1514276	
14	Låskil	Locking wedge	1522837	1
13	Skruv	Screw	1505263	
12	Bricka	Washer	1504899	
11	Glidbussning	Bushing	1514831	
10	Lagerhus	Bearing housing	1521131	
9	Glidbussning	Bushing	1515357	
8	Lagerhus	Bearing housing	1523102	2
7	Lagerhus	Bearing housing	1521137	2
6	Låsplåt	Locking plate	504569	
5	Hydraulcylinder	Hydraulic cylinder	1526197	1
4	Bult	Bolt	1521139	
3	Bult	Bolt	1514829	3
2	Axeltapp	Axle	1521141	2
1	Pressplatta Twin bred	Press plate Twin wide	1514877	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




12	Packning	Gasket	1523932	1
11	Rörklamma	Pipe clamp	1504974	
10	Ledningsrör	Pipe	1523208	2
9	Lock	Cover	1523200	3
8	Hydraulcylinder	Hydraulic cylinder	1526198	2
7	Skruv	Screw	1505262	
6	Skruv	Screw	1505263	
5	Bricka	Washer	1504899	
4	Adapter	Adapter	504730	
3	Låsplatta	Locking plate	504332	2
2	Bult	Bolt	1521140	
1	Transportplatta Twin bred	Transport plate Twin wide	1508899	11
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Twin baklucka smal-Twin Tailgate narrow



Note! The images are for reference only.
Components marked with * contact
spare part branch.




5	Skruv	Screw	1505263	
4	Bricka	Washer	1504899	
3	Låsplatta	Locking plate	504332	2
2	Bult	Bolt	1521140	
1	Press & transportplatta Twin smal	Press & Transport plate Twin narrow	1521217	7
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Press & transportplatta Twin smal-Press & Transport
plate Twin narrow


1526367 Twin baklucka smal-Twin Tailgate
2014-03-13 narrow

Rev. 1 Date: 2014-03-28




18	Skruv	Screw	1505264	
17	Skruv	Screw	1505263	
16	BRICKA	Washer	1507380	
15	Skruv	Screw	1505265	
14	Mutter	Nut	1504839	
13	Bricka	Washer	1504903	
12	Bricka	Washer	1504899	
11	Skruv	Screw	1507699	
10	Täckplåt höger	Cover right	1510044	3
9	Täckplåt vänster	Cover left	1526418	1
8	Täcklock	Cover plate	1523829	1
7	Skyddsstötta	Support leg	1505284	
6	Låshake	Lock latch	1509435	7
5	Gummilishållare sida	Rubber seal holder	1525050	2
4	Gummilishållare	Rubber seal holder	1514505	
3	Rak gummilishållare	Rubber seal holder	1509126	
2	Gummilishållare 90°	Rubber seal holder	1525034	1
1	Tätninglist Twin smal	Rubber seal	1521644	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



3	Induktiv givare	Inductive sensor	1511077	
2	Induktiv givare	Inductive sensor	504768	
1	Slitplast givare	Hard plastic, sensor	1521340	
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




11	Låsmutter M8	Locking nut	1505255	
10	Bricka BRB 8,4	Washer	1504899	
9	Skruv MF6S M8x25 fzb	Screw	1505267	
8	Gångjärn GN237 60x60 (Wiberger)	Hinge	504609	
7	Skyddsstötta	Safety support	504618	
6	Takplåt smal Twin	Roof plate Twin narrow	1510035	6
5	Vinkel	Angle bracket	1509923	
4	Skruv M6S M8x20 fzb	Screw	1505263	
3	Bricka BRB 8,4	Washer	1504899	
2	Låsmutter M8	Locking nut	1505255	
1	Skyddsplåt Twin smal	Cover	1510032	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Press & Transportplatta Twin smal Press & Transport plate Twin narrow




Note! The images are for reference only.
Components marked with * contact
spare part branch.




14	Fjäderplåt	Sensor plate	1521344	
13	Fjäderfäste	Bracket	1522249	3
12	Låsmutter	Locking nut	1505255	
11	Skruv	Screw	1504922	
10	Bricka	Washer	1504899	
9	Skruv	Screw	1510249	2
8	Skruv	Screw	1522843	1
7	Låskil Glidklots	Locing wedge	1523101	1
6	Glidbussning	Bushing	1514702	
5	Skruv	Screw	1505315	2
4	Bricka	Washer	1504901	
3	Plåt	Plate	1508925	
2	Glidbelägg	Sliding skid	1508960	
1	Glidkloss	Sliding block	1508926	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



23	Distans	Spacer	1523073	1
22	Medbringare	Fork	1522899	1
21	Vinkelgivare	Angle sensor	1522902	2
20	Givarfäste	Sensor bracket	1522821	3
19	Nordlock M20	Nordlock M20	1514276	
18	Skruv M6S	Screw	1505263	
17	Bricka	Washer	1504899	
16	Nordlock 12	Nordlock 12	1510522	
15	Skruv	Screw	1508815	
14	Bricka	Washer	1504900	
13	Skruv	Screw	1522842	1
12	Skruv	Screw	1506680	
11	Glidbussning	Bushing	1515357	
10	Låskil	Locking wedge	1522837	1
9	Bult	Bolt	1514829	3
8	Glidbussning	Bushing	1514831	
7	Lagerhus	Bearing housing	1521131	
6	Lagerhus	Bearing housing	1523102	2
5	Låsplåt	Locking plate	504569	
4	Hydraulcylinder	Hydraulic cylinder	1526197	1
3	Bult	Bolt	1521139	
2	Axeltapp	Axle	1521141	2
1	Pressplatta Twin smal	Press plate Twin narrow	1514860	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




13	Packning	Gasket	1523933	1
12	Rörklamma	Pipe clamp	1504974	
11	Ledningsrör	Pipe	1523208	2
10	Lock	Cover	1522917	1
9	Skruv	Screw	1504922	
8	Bricka	Washer	1504899	
7	Skruv	Screw	1507496	
6	Bricka	Washer	1504900	
5	Adapter	Adapter	504730	
4	Låsplatta	Locking plate	504332	2
3	Bult	Bolt	1521140	
2	Hydraulcylinder	Hydraulic cylinder	1526198	2
1	Transportplatta Twin smal	Transport plate Twin narrow	1508932	12
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



Transportplatta twin smal-Transport plate Twin narrow

1521217	Press & Transportplatta Twin smal-Press & Transport plate Twin narrow
2014-03-12	
Rev. 1	Date: 2014-03-27

Lyft Twin bred-Bin lift Twin Wide




Note! The images are for reference only.
Components marked with * contact
spare part branch.




6	Gummiskydd lyftarmar	Rubber cover	1525133	1
5	Gummibuffert	Bumper	1514622	
4	Hydraulcylinder	Hydraulic cylinder	1520063	3
3	Lyftarm komplett Twin	Lift arm right	1520200	
2	Länkstång komplett	Link	1518838	2
1	Lyftarm komplett Vänster	Lift arm Left	1518757	5
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




15	Skruv	Screw	1513374	
14	Segersäkring	Ring, snap	1518844	
13	Plattkil	Wedge	1518850	
12	Skruv	Screw	1519816	
11	Bricka	Washer	1518849	3
10	Stefatätning	Seal	1513246	
9	Vinkelgivare	Angle sensor	1522902	2
8	Givarfäste	Sensor bracket	1518750	2
7	Lyftarmsaxeltapp	Bolt	1518751	
6	Lock lyftarm yttre	Cover	1518734	
5	Lock lyftarm inre	Cover	1518735	
4	Bussning	Bushing	1518752	
3	Distansring	Spacer	1518753	
2	Lyftskydd	Lift arm cover	1506190	6
1	Lyftarm Vänster	Lift arm left	1518728	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




8	Skruv	Screw	1518995	
7	Skruv	Screw	1512953	
6	Låsplatta	Locking plate	504337	2
5	Bult	Bolt	1520415	
4	Bult	Bolt	1518836	
3	Radialtätning	Radial seal	1515636	
2	Bussning	Bushing	1518826	
1	Länkstång	Link arm	1518828	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




13	Skydd lyftstopp	Cover, rubber	1523185	2
12	Skruv	Screw	1512953	
11	Gummibuffert	Bumper	1514622	
10	Låsplatta	Locking plate	504337	2
9	Slangbrottsventil lyft	Hose break valve	1507898	
8	Adapter	Adapter	1505025	
7	Radialtätning	Radial seal	1515636	
6	Bussning	Bushing	1518826	
5	Hydraulcylinder	Hydraulic cylinder	1518811	
4	Bult	Bolt	1518836	
3	Skruv	Screw	1512953	
2	Bult	Bolt	1518836	
1	Låsplatta	Locking plate	504337	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




8	Lyftskydd	Lift arm cover	1506190	6
7	Skruv	Screw	1518995	
6	Bult	Bolt	1520451	2
5	Skruv	Screw	1513374	
4	Stefatätning	Seal	1513246	
3	Lock lyftarm	Cover	1520206	2
2	Bussning	Bushing	1520208	
1	Lyftarm Twin	Lift arm	1520201	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



8	Skruv	Screw	1518995	
7	Skruv	Screw	1512953	
6	Låsplatta	Locking plate	504337	2
5	Bult	Bolt	1520415	
4	Bult	Bolt	1518836	
3	Radialtätning	Radial seal	1515636	
2	Bussning	Bushing	1518826	
1	Länkstång	Link	1518828	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.





10	Skruv	Screw	1512953	
9	Gummibuffert	Bumper	1514622	
8	Låsplatta	Locking plate	504337	2
7	Bult	Bolt	1520415	
6	Slangbrottsventil lyft	Hose break valve	1507898	
5	Adapter	Adapter	1505025	
4	Radialtätning	Radial seal	1515636	
3	Bussning	Bushing	1518826	
2	Hydraulcylinder	Hydraulic cylinder	1518811	
1	Bult	Bolt	1518836	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Lyft Twin smal-Bin lift Twin Narrow




Note! The images are for reference only.
Components marked with * contact
spare part branch.




7	Skydd lyftstopp	Cover, rubber	1523185	2
6	Lyftarm komplett Höger	Lift arm right	1518851	5
5	Lyftskydd	Cover	1506190	6
4	Gummibuffert	Bumper	1514622	
3	Hydraulcylinder	Hydraulic cylinder	1520063	3
2	Lyftarm komplett Twin	Lift arm	1520200	
1	Länkstång komplett	Link	1518838	2
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




15	Vinkelgivare	Angle sensor	1522902	2
14	Givarfäste	Sensor bracket	1518750	2
13	Skruv	Screw	1513374	
12	Segersäkring	Ring, snap	1518844	
11	Plattkil	Wedge	1518850	
10	Skruv	Screw	1519816	
9	Bricka	Washer	1518849	3
8	Stefatätning	Seal	1513246	
7	Lyftarmsaxeltapp	Bolt	1518751	
6	Lock lyftarm yttre	Cover	1518734	
5	Lock lyftarm inre	Cover	1518735	
4	Bussning	Bushing	1518752	
3	Distansring	Spacer	1518753	
2	Lyftskydd	Lift arm caver	1506190	6
1	Lyftarm Höger	Lift arm right	1518852	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




8	Skruv	Screw	1518995	
7	Skruv	Screw	1512953	
6	Låsplatta	Locking plate	504337	2
5	Bult	Bolt	1520415	
4	Radialtätning	Radial seal	1515636	
3	Bussning	Bushing	1518826	
2	Länkstång	Link arm	1518828	2
1	Bult	Bolt	1518836	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.




11	Skruv	Screw	1512953	
10	Bult	Bolt	1518836	
9	Låsplatta	Locking plate	504337	2
8	Skruv	Screw	1512953	
7	Låsplatta	Locking plate	504337	2
6	Slangbrottsventil lyft	Hose break valve	1507898	
5	Adapter	Adapter	1505025	
4	Radialtätning	Radial seal	1515636	
3	Bussning	Bushing	1518826	
2	Hydraulcylinder	Hydraulic cylinder	1518811	
1	Bult	Bolt	1518836	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.



8	Lyftskydd	Lift arm cover	1506190	6
7	Skruv	Screw	1518995	
6	Bult	Bolt	1520451	2
5	Skruv	Screw	1513374	
4	Stefatätning	Seal	1513246	
3	Lock lyftarm	Cover	1520206	2
2	Bussning	Bushing	1520208	
1	Lyftarm Twin	Lift arm	1520201	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




10	Skruv	Screw	1512953	
9	Gummibuffert	Bumper	1514622	
8	Låsplatta	Locking plate	504337	2
7	Bult	Bolt	1520415	
6	Slangbrottsventil lyft	Hose break valve	1507898	
5	Adapter	Adapter	1505025	
4	Radialtätning	Radial seal	1515636	
3	Bussning	Bushing	1518826	
2	Hydraulcylinder	Hydraulic cylinder	1518811	
1	Bult	Bolt	1518836	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Vagga Twin bred-Cradle Twin wide




Note! The images are for reference only.
Components marked with * contact
spare part branch.



6	Axelhylsa	Shaft sleeve	1518790	3
5	Gummifender lyft	Rubber	1520032	
4	Röraxel	Tube axle	1520132	2
3	Bussning	Bushing	1518404	
2	Radialtätning	Seal	1516530	
1	Axelhylsa	Shaft sleeve	1518803	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




10	Låsplatta	Locking plate	504334	2
9	Bult	Bolt	1519796	2
8	Tätningssring	Seal	1506796	
7	Bussning	Bushing	1519795	
6	Skruv	Screw	1512953	
5	Låsmutter	Locking nut	1505258	
4	Skruv	Screw	1506737	
3	Bricka BRB 13	Washer	1504901	
2	Kärllåsklaff Twin bred	Bin lock	1520187	
1	Cylinder komplett	Hydraulic cylinder	1524781	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Vagga Twin smal-Cradle Twin narrow




Note! The images are for reference only.
Components marked with * contact
spare part branch.



6	Gummibuffert Twin smal	Rubber	1509249	
5	Axelhylsa	Shaft sleeve	1518790	3
4	Röraxel	Tube axle	1521286	2
3	Bussning	Bushing	1518404	
2	Radialtätning	Seal	1516530	
1	Axelhylsa	Shaft sleeve	1518803	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev


Note! The images are for reference only.
Components marked with * contact
spare part branch.




10	Skruv	Screw	1512953	
9	Skruv	Screw	1506737	
8	Låsmutter	Locking nut	1505258	
7	Bricka	Washer	1504901	
6	Låsplatta	Locking plate	504334	2
5	Bult	Bolt	1519796	2
4	Tätningring	Seal	1506796	
3	Bussning	Bushing	1519795	
2	Kärllåsklaff Twin smal	Bin lock	1521287	
1	Cylinder komplett	Hydraulic cylinder	1524781	1
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Kärlfångare Twin bred-Bin catcher Twin wide




Note! The images are for reference only.
Components marked with * contact
spare part branch.




20	Glidbussning	Bushing	1525524	1
19	Skruv	Screw	1508833	
18	Skruv	Screw	1525523	1
17	Bricka	Washer	1504901	
16	Vibrationsdämpare	Damper	1523419	1
15	Fjäderfäste	Spring bracket	1521256	
14	Hydraulcylinder	Hydraulic cylinder	1521146	
13	Skruv	Screw	1506538	
12	Låsmutter	Locking nut	1505255	
11	Skruv	Screw	1509719	
10	Bricka	Washer	1504899	
9	Skruv	Screw	1512953	
8	Bussning	Bushing	1518675	
7	Radialtätning	Radial seal	1515635	
6	Distans	Spacer	1518659	
5	Fjäder	Spring	1518705	
4	Låsplatta	Locking plate	504335	2
3	Bult	Bolt	1518676	5
2	Kärlfångarrör	Tube	1520445	2
1	Kärlfångararm	Bin catch arm	1520429	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Kärlfångare Twin smal-Bin catcher Twin narrow




Note! The images are for reference only.
Components marked with * contact
spare part branch.




14	Glidbussning	Bushing	1525524	1
13	Skruv	Screw	1512953	
12	Skruv	Screw	1509719	
11	Skruv	Screw	1509720	
10	Låsmutter	Locking nut	1505255	
9	Bricka	Washer	1504899	
8	Radialtätning	Radial seal	1515635	
7	Bussning	Bushing	1518675	
6	Fjäderfäste	Spring bracket	1521256	
5	Fjäder	Spring	1518705	
4	Bult	Bolt	1518676	5
3	Låsplatta	Locking plate	504335	2
2	Kärlfångarrör	Tube	1521308	2
1	Kärlfångararm	Bin catch arm	1520429	4
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Hydraultank Twin-Hydraulic tank Twin




Note! The images are for reference only.
Components marked with * contact
spare part branch.




28	Filterinsats returfilter	Filter element	1519435	
27	Skruv	Screw	1506640	
26	Skruv	Screw	1515377	
25	Tredobricka M16	Tredo washer	1515376	
24	Bricka	Washer	1504899	
23	Packning	Gasket	1525690	2
22	Andningslock	Breather	1525689	1
21	Lufffilter	Filter, Air	1525403	2
20	Tryckgivare	Pressure sensor	1517308	
19	Adapter	Adapter	1513228	
18	Adapter	Adapter	1516695	
17	Returfilter	Filter, Return	1525276	1
16	Skruv	Screw	1506628	
15	Böj 90 galv	Threaded pipe bend	1514670	
14	Slangnippel	Hose nipple	1507103	
13	Kulventil	Valve	1505815	
12	Adapter	Adapter	1505769	
11	Bricka	Washer	1504900	
10	Skruv	Screw	1509936	
9	Adapter	Adapter	1505758	
8	Adapter	Adapter	1507478	
7	Kulventil	Valve	1505816	
6	Adapter	Adapter	1505811	
5	Dekal tanknivå	Decal, Oil level	1505837	
4	Mätrör oljenivå Twin	Oil level tube	1519378	
3	Vinkel mätrör	Elbow	1505799	
2	Vibrationsdämpare	Damper	1509589	
1	Oljetank Twin	Hydraulic tank	1525404	3
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.

Inspektionslucka HD, MD, Twin Inspection cover HD, MD, Twin



Note! The images are for reference only.
Components marked with * contact
spare part branch.



17	Blindnitmutter	Rivet nut	1504886	
16	Skruv	Screw	1505155	
15	Gångjärn	Hinge	504609	
14	Mutter	Nut	1505145	
13	Skruv	Screw	1506473	
12	Mutter	Nut	1504834	
11	Skruv	Screw	1505142	
10	Bricka	Washer	1504898	
9	Mutter	Nut	1505139	
8	Skruv	Screw	1505138	
7	Bricka	Washer	1505141	
6	Givarfäste	Sensor bracket	1505085	
5	Magnetgivare	Magnetic sensor	1504950	
4	Fäste	Bracket	1505084	
3	Klaffhandtag	Door lock	1505079	
2	Tättningslist	Rubber seal	1504847-2	
1	Inspektionslucka	Inspection cover	1505550	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only.
Components marked with * contact
spare part branch.